



4. Install:
  - Shift rod ①
5. Adjust:
  - Shift rod length ②

**Adjustment steps:**

- Move the shift lever to the “FWD.” position.
  - Loosen the locknuts ②.
  - Turn the shift rod ① so that shift rod free play is 0 mm (in direction where ② can be shortened appropriately) and then turn back the shift rod 1/2 turns.
  - Tighten the locknuts.
6. Fill:
    - Drive chain housing oil  
Refer to “DRIVE CHAIN” in CHAPTER 2.
  7. Adjust:
    - Drive chain slack  
Refer to “DRIVE CHAIN” in CHAPTER 2.