




Display Clutch Cover

First Steps

Remove:

- Bottom Case
- Camera Cable Guide
- LVDS Cable Guide
- Display Clamshell



Tools

- ESD wrist strap
- Clean, soft, lint-free cloth

