

## Outboard Models Covered in This Service Manual

### 35 Models

E35ARLCC J35ARLCC

E35AELCC J35AELCC

### 40 Models

E40RCC J40RCC

E40RLCC J40RLCC

E40BACC J40BACC

E40BALCC J40BALCC

E40ECC J40ECC

E40ELCC J40ELCC

E40TECC J40TECC

E40TELCC J40TELCC

E40TLCC J40TLCC

### 45 Models

45RWLE

45RWYE

45RSE

45RSLE

45RSYE

45RCR

45RCLR

### 48 Models

E48ESLCC J48ESLCC

### 50 Models

E50BECC J50BECC

E50BELCC J50BELCC

E50TELCC J50TELCC

E50TLCC J50TLCC

### 55 Models

55RWLR

55RSH

55RSLH

55RSYH